HD 4640/A

Service
Service
Service



Domestic Appliances and Personal Care

Service Manual

MSH coding 8824 640 0000

PRODUCT INFORMATION

Voltage	:	220-240V
Frequency	:	50-60 Hz
Power consumption	:	1280-1520 W
Coloursetting	:	various
Contents	:	800 cc



SERVICE INFORMATION

1. Element fixation
   The element (6) is fixed with a 3 "Torx" screws.
   The suitable screwdriver can be ordered from Consumer Service Eindhoven under number 4822 395 50449

Published by Philips Domestic Appliances and Personal Care Printed in The Netherlands ©Copyright reserved Subject to modification

4822 729 21983
98/06

PCS 98 694

PHILIPS

HD 4640/A



1	4822 442 01552	Lid complete	blue/green		
-	4822 442 01548	Lid complete	red/orange		
2	This part is not available				
3	4822 464 10479	Base upper	green/yellow		
-	4822 464 10481	Base upper	orange		
4	4822 290 61106	Contactblock			
5	4822 464 10482	Base lower	green/yellow		
-	4822 464 10483	Base lower	orange		
6	This part is not available				
7	This part is not available				
8	4822 134 10127	Lamp		220-250V	
9	4822 276 14021	Switch unit			
10	This part is not available				
11	This part is not available				
12	This part is not available				
13	4822 442 01556	Handle cover	green		
-	4822 442 01557	Handle cover	orange		
14	4822 441 80831	Food			